



DSC 5508Z

Quick Reference

STAY ARMING: HOLD **STAY** (3 secs), **AWAY ARMING:** HOLD **AWAY** (3 secs)
(Motions-off) (Motions-on)

PROGRAMMING NEW MASTER CODE:

ENTER: [*], [5], [Master Code], [40], [new access code], [#]
ENTER: [*], [5], [Master Code], [user code 02-30], [#] to program additional user codes

DOOR CHIME ON/OFF:

Hold **CHIME** (3 SECS), (3-beeps-on/long beep-off)

AT HOME ARMING:

ENTER: [*], [9], [then your access code], (bypass' interior zones and eliminates delay)

TROUBLE LIGHT:

ENTER: [*], [2], (each zone represents a trouble condition, check index in manual)

MEMORY LIGHT:

ENTER: [*], [3] (displays last violated zone)

BYPASS:

ENTER: [*], [1], [zone (s) to be bypassed 01-08], [#]

OVERRIDE BYPASS WHEN SYSTEM IS ARMED

ENTER: [*], [1]

TO RESET SMOKES:

HOLD **RESET** (3 secs)

TO CANCEL: (resets improper code), (to jump out of memory, bypass or trouble modes)

ENTER: [#]